Quaestor node

The first node in the Quaestor Knowledge Browser is the Quaestor node. This node provides access to all information about intrinsic function, Attribute overview, Dimension overview and Constants & standard parameters overview.

The sub-nodes of the Quaestor node are connected to explanation retrieved from the Quaestor wiki. All information downloaded from the internet requires an Internet connection to http://www.quaestor.org . See the flash demo... for a view of the behavior.

blocked URL

In the picture above you also see the Newqkb node. This node indicates an empty knowledge base to start with. **Please note that End-Users and Domain Experts will not see the Newqkb node due to the lack of knowledge engineering rights.**

Functions sub-node

Selecting this sub-node will show all intrinsic functions:

blocked URL

Attributes sub-node

Selecting this sub-node will show all attributes:

blocked URL

Dimensions sub-node

Selecting this sub-node will show all dimensions:

blocked URL

Constants & standard sub-node

Selecting this sub-node will show all constants and reserved parameters:

blocked URL

Quaestor interface

Copyright © 2022, MARIN